

STANDARD RAISED BED

(H) 150MM X (W) 1.2M X (L) 1.2M

CONTENTS

4	WOOD BOARD - 1.2M X 150MM X 32MM
4	CORNER FIXING PEG 150MM
24	SCREWS 4.5MM X 60MM

ASSEMBLY PROCESS

STEP 1: To start, place four panels of wood on the floor (2 width and 2 length panels) in a rectangular shape. Ensure the longest boards are on the inside as per image 1. Drill 2 screws inwards from the outside panels to secure the panels into place.

STEP 2: Once screwed, place the peg against the corner of the inside of the rectangle. Ensure you are on a flat surface and the peg is sat flush with the top of the panel. Drill two screws into each plank into each side (drilling from the outside). Be careful to avoid hitting the screws which you have put into the adjacent plank. Repeat this for all four corners.

STEP 3: Once you have finished building the sides, the raised bed is complete. Two people are required to move it. Place onto your desired area.

