

STANDARD CAGE (W) 1.8M X (L) 4.98M

PLEASE NOTE: A mallet is usually required to tap the joiners into the tubes. Please ensure the joiners are fully submerged into the aluminium.

CONTENTS

2	13MM X 1.08M ALUMINIUM TUBE
4	13MM X 900MM ALUMINIUM TUBE
10	13MM X 900MM ALUMINIUM EXTENSION TUBE
4	13MM X 600MM ALUMINIUM TUBE
8	16MM UPRIGHTS
4	JOINER CORNER & 4 TEES (OR 8 BUILD A BALLS)

IF ORDERED WITH COVER

1	COVER
26	STEEL PEGS
16	13MM CLIPS
16	16MM CLIPS

HEIGHT TABLE		
ERECTED HEIGHT	UPRIGHT HEIGHT	PUSH INTO SOIL
1.2M	1.5M	300MM
900MM	1.2M	300MM
700MM	900MM	200MM
500MM	600MM	100MM

ASSEMBLY PROCESS

STEP 1: The legs are made up of the larger tubes (16mm). Push a build a ball or joiner onto each one (refer to the cage diagram).

STEP 2: Connect the 900mm + 900mm extension tube to create the 1.8m width bars.

STEP 3: Connect the 1.08m + 900mm extension tube to create the 1.98m length bars.

Connect the 600mm + 900mm extension pole together to create a 1.5m length bars.

Connect the 1.5m + 1.5m + 1.98m poles together with two tee joiners in between to create the 4.98m length bars.

Connect the 1.98m + 1.5m + 1.5m tubes together with 2 tee joiners between them to create the 4.98m length bars.

STEP 4: Push the legs (16mm uprights) into the ground to create your erected height (refer to the height table).

STEP 5: Lay cover (if ordered) over the frame and secure using the 16mm clips on each leg, and equally spacing the 13mm clips on the crossbars. Bury the ends of the cover and secure with pegs.

Please Note: If due heavy forecast of snow please remove the roof netting beforehand.)

